



RX6 Receiver

Changing the headphone lead

With one hand hold the receiver, and with the other hand hold the headphone lead at the end nearest the receiver body, place your thumb on the back of the receiver and your first finger around the headphone lead. Lift the lead towards you until the plastic insert lifts slightly away from the box, then firmly pull the lead directly away from the box to remove it.

When inserting a new headphone lead, be careful not to bend the metal pins of the connector which is attached to the circuit board inside the receiver.

